

# LEJON KEMI

## FPG Washing Bags for breathing masks

Lejon Kemi's unique washing bags have been specially developed for washing breathing masks in a washing machine. The bag provides good protection against mechanical damage during washing, while the bags' microfibre material helps to ensure effective and gentle mechanical processing of dirty mask surfaces during washing. The washing bag must be used in conjunction with Lejon Kemi FPG Wash and Lejon Kemi's washing program for breathing masks. FPG Wash is a liquid detergent specially developed for washing breathing masks and protective clothing (firefighter suits) in washing machines. The detergent effectively loosens soot, oil, grease and other dirt, while remaining gentle on the material.

### User instructions for washing breathing masks in a washing machine

1. Follow the breathing mask manufacturer's instructions/recommendations for cleaning breathing masks.
2. Place the breathing masks into the protective bags and carefully close these by tightening the cords and securing with the cord stop. NB Wear plastic or rubber protective gloves. Avoid skin contact with soot.
3. Place the washing bags and breathing masks in the washing machine.
4. Wash as many masks as possible each time, but no more than the maximum number indicated by the washing machine manufacturer. (Normally max. 8-12 masks per wash in a large washing machine)
5. Check that there is sufficient detergent (Lejon Kemi FPG Wash) and that the water supply to the machine is open.
6. Set the machine's washing program to washing of breathing masks (but max. 50° C)
7. Start the washing machine.
8. After washing remove the masks from their bags.
9. Check the masks visually for cleanness and any damage. Excessively soiled breathing masks with dirt and soot may require further washing and/or additional manual cleaning.
10. Shake out the water from the inside of the mask and hang it to dry at max 50° C.
11. Washing bags can be replaced in the washing machine and spin-dried to speed up drying (max 60° C in drying cabinet).
12. After washing: Turn off the washing machine and, if necessary, the water supply. Allow the door to the washing drum to stand open.

### Lejon Kemi FPG Wash

See separate product information on the label and the safety data sheet.

### Washing program for breathing masks

Only Lejon Kemi's washing program specially designed for washing breathing masks may be used. If there is no such program, contact your washing machine supplier. **NB.** Recommended washing and rinsing water temperature max 50 °C.

### Environmental information

The washing bag is made from microfibre material environmentally approved under Nordic Swan Ecolabel criteria, Class 2.

Packaging: 6 washing bags/carton. Art. no.: 31 0006 01

2022-06-17/i.L

**Lejon Kemi AB – Developing environmentally friendly chem.-technical products**  
Fritz Janssons väg 20, SE-184 70 Åkersberga - Customer contact, Tel.: + 46 (0)76-827 00 96  
E-mail: [info@lejonkemi.se](mailto:info@lejonkemi.se) Website: [www.lejonkemi.se](http://www.lejonkemi.se)