

Guidelines for cleaning of breathing apparatus and breathing masks with Lejon Kemi products.

Cleaning of breathing apparatus (without breathing masks) in PPE dish washers (spray washers) with Lejon Kemi products.

Producer of PPE	Cleaning products	Dosing	Max cleaning temp.	Cleaning time	Rinsing temp.
Interspiro	FFE Cleaner	1 % - (3 %)	60 C	20 - 30 min	60 C
	SRP Defoamer	0.1 %			
MSA Safety Excl. air cylinders	FFE Cleaner	1 % - (3 %)	50 C	30 - 45 min	50 C
	SRP Defoamer	0.1 %			
Dräger	FFE Cleaner	1 % - (3 %)	(57 C) - 60 C	20 min	60 C
	SRP Defoamer	0.1 %			
Scott Excl. USA. Kanada	FFE Cleaner	1 % - (3 %)	55 C	20 min	55 C
	SRP Defoamer	0.1 %			

Cleaning of breathing masks with antifog film on visors in "small" PPE dishwashers (spray washers)

Producer of PPE	Cleaning products	Dosing	Max cleaning temp.	Cleaning time	Rinsing temp.
Interspiro	FFE Cleaner	1.0 %	50 C	20 - 30 min	50 C
	SRP Defoamer	0.1 %			
MSA Safety	FFE Cleaner	1.0 %	50 C	20 - 30 min	50 C
	SRP Defoamer	0.1 %			
Dräger	FFE Cleaner	1.0 %	50 C	20 - 30 min	50 C
	SRP Defoamer	0.1 %			
Scott Excl. USA. Kanada	FFE Cleaner	1.0 %	50 C	20 min	50 C
	SRP Defoamer	0.1 %			

Cleaning of breathing masks without antifog film on visors in "small" PPE dishwashers (spray washers)

Producer of PPE	Cleaning products	Dosing	Max cleaning temp.	Cleaning time	Rinsing temp.
Interspiro	FFE Cleaner	1.0 %	60 C	20 - 30 min	60 C
	SRP Defoamer	0.1 %			
MSA Safety	FFE Cleaner	1.0 %	50 C	20 - 30 min	50 C
	SRP Defoamer	0.1 %			
Dräger	FFE Cleaner	1.0 %	60 C	20 min	60 C
	SRP Defoamer	0.1 %			
Scott Excl. USA. Kanada	FFE Cleaner	1.0 %	50 C	20 min	50 C
	SRP Defoamer	0.1 %			

Cleaning of breathing masks in washing machines with Lejon Kemi detergent, washing bags and Lejon Kemi washing programme. This method can be used on masks with or without antifog film.

Producer of PPE	Cleaning product	Dosing	Max cleaning temp.	Cleaning time	Rinsing temp.
Interspiro	FPG Wash	0.4 - 0.6 %*	50 C	40 min + rinsing	50 C (First rinse)
MSA Safety	FPG Wash	0.4 - 0.6 %*	50 C	40 min + rinsing	50 C (First rinse)
Dräger	FPG Wash	0.4 - 0.6 %*	50 C	40 min + rinsing	50 C (First rinse)
Scott	FPG Wash	0.4 - 0.6 %*	50 C	40 min + rinsing	50 C (First rinse)

* Dosing of FPG Wash is calculated on the water level in the washing machine and on water hardness.

Disinfection of breathing masks: Use Cleanox disinfectant according to the instructions for the product.

NOTE! Read product data sheets, labels, MSDS for cleaning products for efficient and safe use and follow the breathing apparatus manufacturer's instructions for cleaning of breathing apparatus and masks.
Cleaning result = Cleaner (type and dosage) + Temperature + Time + Mechanical treatment + Rinsing